7. Installation is straight forward and simple for a licensed electrician. Most systems are 208 Volts, 3 Phase, WYE configuration, 5 wires (3 hots, 1 neutral, 1 ground) input and output. There are five wires going in from the utility company or main electrical panel and five wires going out to the elevator. Operation after turning the system on is completely automatic.